


Quick Setup and Installation Guide


For more detailed information, insert the Installation Disc into the PC and click the **User Guide** button on the Setup Launcher main page.


Unpack:




1 Remove tape and packing materials


(a) Remove tapes.






(continued on next page)










c Remove cardboard.






Squeeze latches to open clamshell





Connect power








Choose display language







If Language option is not available, see Selecting the Security Level on page 12 of the User's Manual.




3 Install ink cartridges










© Open printhead latch fully.



d Remove caps.


Do not discard caps!





(e) Remove cover from printhead




f Slowly remove tape from electrical contacts and nozzles








Check that ink is flowing through the tubes on both sides of the printhead.




5 Load sample media




Flat side against media roll.

6 Print test label

Requires 6" x 4" (included as sample media) or 4" x 6" labels with inter-label gap.



Sample PQ Plot 6x4



Top Section:

- Lines are defined with no missing nozzles
- Lines are printed in order: Yellow, Black, Cyan, Black, Magenta
- Vertical dashed lines are straight

Middle Section:

- All yellow, black, cyan, black, magenta lines are printed
- No color mixing on the color bars
- Numbers 1, 3, 5 are visible

Bottom Section:

- Lines are defined with no missing nozzles
- Lines are printed in order: Yellow, Black, Cyan, Black, Magenta


Overall:

• No streaking or smearing


7 Install printer driver

Before installing printer driver, ensure the computer meets minimum system requirements (see "System Requirements" on page 72 of the User's Manual).


To connect printer to computer using USB








d Connect USB cable when prompted.



To connect printer to network

a Connect printer to network using Ethernet



b If you will be using DHCP to set the IP Address, skip to step **c**.

To assign the printer a Static IP address, please see Selecting the Security Level on page 12 of the User Manual before proceeding to step c.



 (\mathbf{d})

 \mathbf{e}



